The temperature controller is for APEX printerhead to keep the ink temperature. It is recommended to use when room temperature below 15  $^{\circ}$ C, can help improve the fluency of ink to prevent printing breakage and color loss.